


Typical installation of floor channel into trapped 'G' series 'LD' version gully body.

Install channel generally in accordance with drawing 'Instal 7' connecting outlet to trap as follows.

1. Ensure that body and collar are the 'LD' versions, without a thread where the channel spigot enters.
2. Position body and fix into place.
3. Screw 3 no. studs into body leaving a minimum of 30mm protruding, seal around studs with a proprietary mastic sealant.
3. Place cast iron collar and sealing ring onto the channel outlet and lower into place setting the channel at the required FFL.
4. Secure collar using nuts and washers provided ensuring that sealing ring is compressed against channel outlet.

© 2006

ISS. No.		DRAWN	DC	3-2-06	TITLE TYPICAL INSTALLATION OF FLOOR CHANNELS INTO TRAPPED 'G' SERIES GULLY BODY.		
C.N. No.		CHECKED					
DATE		APPRVD.					
		MATERIAL 50910011#1			SCALE NTS	DRG. No. <b>INSTAL 13</b> SHEET 1 OF 2	ISSUE No. 6

WADE INTERNATIONAL LTD., THIRD AVENUE, HALSTEAD, ESSEX, CO9 2SX.

TEL: 01787 475151 FAX: 01787 475579

e-mail: tech@wade.eu website: www.wade.eu